

## **Unfolding the ProV1**

1. Loosen the four bolts securing the upright posts to the base by 1-2 full turns. Do not remove them.
2. Unfold the upright posts until they rest flush against the base, ensuring the bolts align with the grooves in the mounting plate.
3. Fully tighten all four bolts to secure the uprights.

## **Installing Pedals on the ProV1 Inverted Pedal Plate**

1. Adjusting Pedal Height:
  - Loosen the bolts on the side plates and slide the plates within the channels of the extrusions to set the desired pedal height.
2. Mounting the Pedals:
  - Attach the pedals to the bottom extrusion rail first. Tighten bolts to 75% tightness
  - Attach the top extrusion rail to the pedals and tighten bolts to 75% tightness
3. Adjust the pedal angle as needed and tighten all remaining bolts completely

## **Mounting the Wheelbase**

4. Loosen the four side bolts on the wheelbase mounting plate
5. Slide the plate to the right, then lift it up and to the left to fully detach it from the chassis
6. Attach your wheelbase to the mounting plate using the wheelbase manufacturer's specified bolt pattern
7. Reinstall the mounting plate onto the chassis by reversing step 2: Slide left, then lower it down and to the right
8. Center your wheelbase and fully tighten all bolts

## **Installing a Seat (Generic with Seat Sliders)**

1. Mount the two extrusion rails directly onto the seat sliders
2. Loosen the side plate bolts on the chassis by a few turns—do not remove them
3. Position the seat onto the chassis, aligning it at the desired distance from the pedals and wheel
4. Slide the side plates to align with the seat mounting points
5. Fully tighten all bolts to secure the seat

Congratulations, you've successfully assembled your ProV1!